


PARTS LIST

NO.	NAME	NO.	NAME
651	CASE	847B	GASKET, SHAFT SLEEVE (LOCKED)
652	CASE COVER	847C	GASKET, CASE
653	BEARING CAP	848	GLAND STUD
654	CASING RING	3821A	BEARING LOCKNUT (THRUST)
655	GLAND	3821B	BEARING LOCKNUT (PLAIN)
656	SHAFT	3820A	BEARING LOCKWASHER (THRUST BRG.)
657	IMPELLER	3820B	BEARING LOCKWASHER (PLAIN BRG.)
659A	SHAFT SLEEVE	2503A	BEARING, THRUST
659B	SHAFT SLEEVE (LOCKED)	2503B	BEARING, PLAIN
660	WATER SEAL RING	2572	SNAP RING
661	SLINGER	3205	GREASE FITTING
704	PLAIN BEARING HEAD	3245A	KEY, COUPLING
705	BEARING HOUSING	3245B	KEY, IMPELLER
706	THRUST BEARING HEAD	3470A	PACKING, STUFFING BOX
731	BEARING RING	3470B	PACKING, SHAFT SLEEVE
818	BEARING HOUSING GASKET	3490	ROLL-PIN
836	SHAFT SLEEVE NUT	3611	LONG LOK SCREW
847A	GASKET, SHAFT SLEEVE	3822	FLEX LOC NUT



INTERNAL WATER SEAL PIPING ARRANGEMENT WHEN REQUIRED

SECTIONAL ASSEMBLY AND PARTS LIST FOR "DTB" PUMPS

REV. NO.	REVISIONS	DATE	BY	CHKD.	DATE	NO.	REVISIONS	DATE	BY	CHKD.
1	REVISED PARTS LIST & ADDED VIEW OF ROTOR									
2	REVISED PART NO'S ON BPG ITEMS & ADDED PUMP REQUIREMENTS									
3	PART NO. 3822 WAS POINTING TO GLAND SLINGER BOLT NUT									

WARREN PUMP
 SECTIONAL ASSEMBLY
 999F0261